

Jumbo® Pump installation

PUMP
DISCHARGE

WATER DUMP

1/2" HOSE FROM HEAT
EXCHANGER



3" RUBBER PUMP SUCTION

LOCKING PIN

HINGE - SWINGS OUT FOR
MAINTENANCE